

B.Tech FIFTH SEMESTER

COMPUTER SCIENCE AND ENGINEERING (CSE & CSE(AI))

COMPUTER VISION LABORATORY

CSE_3181



LABORATORY MANUAL

Vision

Excellence in Emerging Technical Education through Research, Innovation, and Teamwork

Mission

Educate students professionally to face social challenges by providing a healthy learning environment grounded well in emerging technologies, value based education, creativity, and nurturing teamwork.

Goal

Our goal is to be a world class technical institution fostering innovation, leadership and entrepreneurial spirit.

Program Outcomes:

- 1. **Engineering knowledge:** Apply the knowledge of mathematics, science, engineering fundamentals, and an engineering specialization to the solution of complex engineering problems.
- 2. **Problem analysis:** Identify, formulate, review research literature, and analyze complex engineering problems reaching substantiated conclusions using first principles of mathematics, natural sciences, and engineering sciences.
- 3. **Design/development of solutions:** Design solutions for complex engineering problems and design system components or processes that meet the specified needs with appropriate consideration for the public health and safety, and the cultural, societal, and environmental considerations.

- 4. Conduct investigations of complex problems: Use research-based knowledge and research methods including design of experiments, analysis and interpretation of data, and synthesis of the information to provide valid conclusions.
- 5. **Modern tool usage:** Create, select, and apply appropriate techniques, resources, and modern engineering and IT tools including prediction and modeling to complex engineering activities with an understanding of the limitations.
- 6. **The engineer and society:** Apply reasoning informed by the contextual knowledge to assess societal, health, safety, legal and cultural issues and the consequent responsibilities relevant to the professional engineering practice.
- 7. **Environment and sustainability:** Understand the impact of the professional engineering solutions in societal and environmental contexts, and demonstrate the knowledge of, and need for sustainable development.
- 8. **Ethics:** Apply ethical principles and commit to professional ethics and responsibilities and norms of the engineering practice.
- 9. **Individual and team work:** Function effectively as an individual, and as a member or leader in diverse teams, and in multidisciplinary settings.
- 10. **Communication:** Communicate effectively on complex engineering activities with the engineering community and with society at large, such as, being able to comprehend and write effective reports and design documentation, make effective presentations, and give and receive clear instructions.
- 11. **Project management and finance:** Demonstrate knowledge and understanding of the engineering and management principles and apply these to one's own work, as a member and leader in a team, to manage projects and in multidisciplinary environments.
- 12. **Life-long learning:** Recognize the need for, and have the preparation and ability to engage in independent and life-long learning in the broadest context of technological change.

CONTENTS

S.No	TITLE	Pg. No
	COURSE OBJECTIVES AND OUTCOMES	iii
	EVALUATION PLAN	iii
	INSTRUCTIONS TO THE STUDENTS	iv
	INTRODUCTION	v
1	Basic operations	1
2	Intensity Transformations	3
3	Image Enhancement	5
4	Image Denoising Using Filters	8
5	Edge Detection	9
6	Feature Description Using SIFT	11
7	Geometric Transformations	13
8	Camera Calibration	15
9	Object Tracking	17
10	KLT Feature Tracker	19
11	Face Detection	21
12	Car Detection	22

Course Objectives

This laboratory course enables students to

- Implement image enhancement techniques for feature extraction
- Implement different feature detection methods and understand mathematics of description methods.
- Implement methods for different camera models and their calibration.
- Implement object recognition through different learning algorithms.

Course Outcomes

At the end of this course, students will be able to

- 1. Apply the concepts of image formation, colour models and linear filtering.
- 2. Understand the mathematics behind feature detection and description methods.
- 3. Demonstrate a thorough understanding of fundamental concepts in camera calibration.
- 4. Implement object tracking algorithms.
- 5. Design object recognition and categorization from images.

Evaluation Plan

- Internal Assessment Marks: 60 marks
- Continuous evaluation: 40 Marks
 - The Continuous evaluation assessment will depend on punctuality, designing right algorithm, converting algorithm into an program, maintaining the observation note and answering the questions in viva voce.
 - o Internal Exam :20 Marks

Instructions to the Students

> Pre- Lab Session Instructions

- Students should carry the Lab Manual Book and the required stationery to every lab session
- Be on time and follow the institution's guidelines
- Must Sign in the log register provided
- Make sure to occupy the allotted seat and answer the attendance
- Adhere to the rules and maintain the decorum.

> In- Lab Session Instructions

- Follow the instructions on the allotted exercises
- Show the program and results to the instructors on completion of experiments
- On receiving approval from the instructor, copy the program and results in the Lab record
- Prescribed textbooks and class notes can be kept ready for reference if required

> General Instructions for the Exercises in Lab

- Implement the given exercise individually and not in a group.
- The programs should meet the following criteria:
 - ☐ Programs should be interactive with appropriate prompt messages, error messages if any, and descriptive messages for outputs. ☐ Programs should perform input validation (Data type, range error, etc.) and give appropriate error messages and suggest corrective actions. ☐ Comments should be used to give the statement of the problem and every function should indicate the purpose of the function, inputs and

 - ☐ Statements within the program should be properly indented.
 - ☐ Use meaningful names for variables and functions.
 - ☐ Make use of constants and type definitions wherever needed.
- Plagiarism (copying from others) is strictly prohibited.
- In case a student misses a lab class, he/ she must ensure that the experiment is completed during the repetition lab with the permission of the faculty concerned.
- Questions for lab tests and examination are not necessarily limited to the questions in the manual, but may involve some variations and / or combinations of the questions.

INTRODUCTION

This course is designed to provide hands-on experience in computer vision, a field that focuses on developing algorithms and techniques for interpreting visual data from the world around us. The course covers a wide range of topics, starting with an introduction to the OpenCV library, one of the most popular computer vision libraries available today. We will also cover image and video manipulation, including operations at the pixel level, image enhancement techniques, and feature extraction methods. This course focuses also on more advanced topics, including camera models and calibration, stereo vision, tracking, and classification tasks such as face detection and recognition. Throughout the course, students will gain experience with implementing algorithms and techniques using OpenCV and other tools in a Linux environment. By the end of the course, students will have a solid understanding of the theory and practice of computer vision, as well as experience working on real-world applications.

→ About Python and Open-CV libraries

Python is an interperted high-level programming language for general purpose programming. It supports multiple programming paradigms including object oriented and procedural, and has a large and comprehensive standard library.

PyCharm is a cross-platform IDE used in computer programming specifically for Python. The platform developed by JetBrains is mainly used in code analysis, graphical debugger etc... It supports web development with Django as well as Data Science with Anaconda.

OpenCV is a library of Python bindings designed to solve computer vision problems. (Open Source Computer Vision Library) is an open-source computer vision and machine learning software library. OpenCV was built to provide a common infrastructure for computer vision applications and to accelerate the use of machine perception in commercial products. By using it, one can process images and videos to identify objects, faces, or even the handwriting of a human. When it is integrated with various libraries, such as NumPy, Python is capable of processing the OpenCV array structure for analysis.

> Requirements:

Hardware:

- A computer with at least 8GB of RAM and a modern processor.
- 32- or a 64-bit computer.
- A graphics card with CUDA support may be beneficial for certain tasks.

Software:

- Windows operating system
- OpenCV library installed and configured.
- Python 3.11
- PyCharm IDE

> Python Installation Procedure

- Download Python from https://www.python.org/downloads/
- Once the download is completed, run the .exe file to install Python.
- To check if python is successfully installed type the following in command prompt

Python --version

Check if pip is installed successfully in the system
 pip -V

> PyCharm IDE Installation Procedure

- To download PyCharm visit the website https://www.jetbrains.com/pycharm/download/ and click the "DOWNLOAD" link under the Community Section.
- Once the download is complete, run the .exe file for installing PyCharm.

> Import OpenCV on PyCharm

- Go to the *Python Packages* option at the bottom of the IDE window.
- Search for "opency-python" and select the option from PyPI. Click on *Install Package*.
- The package is installed and is visible in the "Installed" Tab.
- To remove the package, click on the package name (here : opency-python) from the *Installed*. Click three dots, select "*Delete Package*".

PROGRAMS

1. Basic Operations

- a) Familiarize the students with the basic functions of OpenCV such as cv2.imread(), cv2.imshow(), and cv2.waitKey() and Write a basic Python program to load and display an image using OpenCV
 - cv2.imread(): This function is used to read an image from a file into a numpy array, which can then be manipulated using OpenCV. The function takes one argument, which is the path to the image file. It returns a numpy array representing the image.
 - **cv2.imshow():** This function is used to display an image in a window on the screen. The function takes two arguments: the name of the window (as a string), and the image data (as a numpy array).
 - cv2.waitKey(): This function waits for a key event from the user. It takes one argument, which is the delay in milliseconds. If the delay is set to 0, the function waits indefinitely for a key event.

Procedure:

Step 1: Load the image from the file

Step 2: Display the image in a window

Step 3: Wait for a key press and then close the window

```
import cv2
# Load the image from the file
img = cv2.imread('image.jpg')
# Display the image in a window
cv2.imshow('Image', img)
# Wait for a key press and then close the window
cv2.waitKey(0)
cv2.destroyAllWindows()
```

b) Write a program to read a video file and display it on the screen

Procedure:

- **Step 1:** Import the necessary libraries: cv2 for OpenCV and numpy for numerical operations.
- **Step 2:** Define the video file path using cv2.VideoCapture() function.
- **Step 3:** Check if the video file is opened correctly by calling cap.isOpened() function.
- **Step 4:** Loop through each frame of the video using while loop.
- **Step 5:** Read the frame using cap.read() function.
- **Step 6:** Check if the frame is empty using if statement.
- **Step 7:** Display the frame on the screen using cv2.imshow() function.
- **Step 8:** Wait for a key event to occur using cv2.waitKey() function.
- **Step 9:** Check if the key pressed is 'q' to quit the video using if statement.
- **Step 10:** Release the video capture object using cap.release() function.
- **Step 11:** Close all windows using cv2.destroyAllWindows() function.

```
import cv2
# open the video file
cap = cv2.VideoCapture('video.mp4')
# loop through frames in the video
while cap.isOpened():
   # read a frame
   ret, frame = cap.read()
   # check if the frame was successfully read
   if ret:
         # display the frame on the screen
         cv2.imshow('Video', frame)
         # wait for a key press for 25 milliseconds
         if cv2.waitKey(25) & 0xFF == ord('q'):
               break
         else:
               break
   # release the video capture object and close all windows
   cap.release()
   cv2.destroyAllWindows()
```

2. Intensity Transformations

a) Write a program to perform Image Negation

Procedure:

- **Step 1:** Import the necessary OpenCV libraries.
- **Step 2:** Load the input image using the cv2.imread() function.
- **Step 3:** Convert the input image to grayscale using cv2.cvtColor() function.
- **Step 4:** Compute the negative of the grayscale image using the cv2.bitwise_not() function.
- **Step 5:** Display the input image and the negative image using the cv2.imshow() function.
- **Step 6:** Wait for a key press using the cv2.waitKey() function.
- **Step 7:** If the key pressed is 's', save the negative image using the cv2.imwrite() function.
- **Step 8:** Destroy all windows using the cv2.destroyAllWindows() function.

Program:

```
import cv2
# Load input image
img = cv2.imread('input_image.jpg')
# Convert input image to grayscale
gray = cv2.cvtColor(img, cv2.COLOR_BGR2GRAY)
# Compute negative of the grayscale image
neg = cv2.bitwise_not(gray)
# Display the input image and negative image
cv2.imshow('Input Image', img)
cv2.imshow('Negative Image', neg)
# Wait for a key press
key = cv2.waitKey(0)
# If the key pressed is 's', save the negative image
if key == ord('s'):
      cv2.imwrite('negative_image.jpg', neg)
# Destroy all windows
cv2.destroyAllWindows()
```

b) Write a program to perform Log transformation on the image

Procedure:

Step 1: Import the necessary OpenCV modules and the input image.

- **Step 2:** Define the gamma value and the constant C for log transformation.
- **Step 3:** Convert the input image to grayscale if it is a color image.
- **Step 4:** Perform the log transformation using the cv2.log() function and the given formula:

```
output_image = C * log(1 + input_image)
```

Step 6: Display the input and output images side by side using cv2.hconcat() and cv2.imshow() functions.

Step 7: Save the output image using the cv2.imwrite() function.

```
import cv2
import numpy as np
# Read input image
img = cv2.imread('input image.jpg')
# Define gamma value for gamma correction
gamma = 1.5
# Define constant C for log transformation
C = 20
# Convert input image to grayscale
gray_img = cv2.cvtColor(img, cv2.COLOR_BGR2GRAY)
# Perform log transformation
log_img = C * np.log(1 + gray_img)
# Display input and output images side by side
result = cv2.hconcat([gray_img, log_img])
cv2.imshow(Log transformation', result)
# Save the output image
cv2.imwrite('output_image.jpg', result)
cv2.waitKey(0)
cv2.destroyAllWindows()
```

3. Image Enhancement

a) Write a program to enhance the image using piece-wise linear transformation by gray-level slicing.

Procedure:

Step1: Read input image

Step2: Find width and height of the image

Step3: Create an zeros array to store the sliced image

Step4: Specify the min and max range

Step5: Loop over the input image and if pixel value lies in desired range set it to 255

Step6: otherwise set it to desired value

Step7: Wait for a key press using the cv2.waitKey() function.

Step8: Write the original and sliced images using imwrite() function

Step9: Destroy all windows using the cv2.destroyAllWindows() function.

```
Import cv2
img = cv2.imread('background.jpg', 0)
# Find width and height of image
row, column= img.shape
# Create an zeros array to store the sliced image
img1 = np.zeros((row,column),dtype = 'uint8')
# Specify the min and max range
min range = 80
max_range = 140
# Loop over the input image and if pixel value lies in desired range
set it to 255
# otherwise set it to desired value
for i in range(row):
      for j in range(column):
        if img[i,j]>min_range and img[i,j]<max_range:</pre>
              img1[i,j] = 255
        else:
```

```
img1[i,j] = img[i-1,j-1]
cv2.imwrite('Original.jpg', img)
cv2.imwrite('slicedimage.jpg', img1)
cv2.waitKey(0)
cv2.destroyAllWindows()
```

b) Write a program to enhance the contrast of the image using Histogram Equalization

Procedure:

Step1: Import necessary libraries

Step2: Read the input image

Step3: Set the grid size and Plot the original image

Step4: Compute the histogram of the image

Step5: Plot and display the histogram of the image

Step6: Applying the Histogram equalization using the cv2.equalizeHist() function

Step7: Displaying the histogram equalized image

```
# Importing OpenCV
import cv2

# Importing numpy
import numpy as np

# Importing matplotlib.pyplot
import matplotlib.pyplot as plt

# Reading the image
img = cv2.imread(r"C:\Users\tushi\Downloads\PythonGeeks\deer.png")
img = cv2.cvtColor(img, cv2.COLOR_BGR2RGB)
img_1 = cv2.cvtColor(img, cv2.COLOR_BGR2GRAY)

# Setting the grid size
plt.figure(figsize=(20,20))
```

```
# Plotting the original image
plt.subplot(221)
plt.title('Original')
plt.imshow(img)
# Plotting the histogram for the image
img_hist = cv2.calcHist([img_1],[0],None,[256],[0,256])
plt.subplot(222)
plt.title('Histogram 1')
plt.plot(img_hist)
# Plotting the histogram using the ravel function
plt.subplot(223)
plt.hist(img_1.ravel(), 256, [0,256])
plt.title('Histogram 2')
# Applying the Histogram equalization using the cv2.equalizeHist()
function
final_image = cv2.equalizeHist(img)
# Displaying the image
cv2.imshow('Histogram Equalization', final_img)
cv2.waitKey(0)
cv2.destroyAllWindows()
```

4. Image Denoising Using Filters

Implement the following low-pass and high-pass filters to improve the quality of the image: a) mean filter b) median filter c) Laplacian filter

Procedure:

- **Step 1:** Load the image using cv2.imread() function
- Step 2: Apply spatial filtering using filter function and kernel matrix
- **Step 3:** Display the filtered image using cv2.imshow() function
- **Step 4:** Wait for user input using cv2.waitKey() function
- **Step 5:** Destroy all windows using cv2.destroyAllWindows() function

```
import cv2
import numpy as np
# Load image
img = cv2.imread('image.jpg', cv2.IMREAD_GRAYSCALE)
# Define kernel matrix
kernel = np.ones((5, 5), np.float32) / 25
# Apply mean filtering
mean filtered = cv2.filter2D(img, -1, kernel)
# Apply median filtering
median_filtered = cv2.medianBlur(img, 5)
#Sharpen the image using the Laplacian operator
sharpened_image2 = cv2.Laplacian(image, cv2.CV_64F)
# Display filtered images
cv2.imshow('Original Image', img)
cv2.imshow('Mean Filtered Image', mean_filtered)
cv2.imshow('Median Filtered Image', median_filtered)
# Wait for user input
cv2.waitKey(0)
# Destroy all windows
cv2.destroyAllWindows()
```

5. Edge Detection

Implement edge detection using Sobel and Canny edge detectors using OpenCV

Procedure:

- **Step 1:** Read the input image using OpenCV's imread() function.
- **Step 2:** Convert the image to grayscale using cvtColor() function.
- **Step 3:** Apply Gaussian blur on the grayscale image using GaussianBlur() function to remove noise.
- **Step 4:** Apply Sobel operator on the blurred image using Sobel() function to detect edges in x and y directions.
- **Step 5:** Combine the edges detected in x and y directions to obtain the final edges using bitwise or() function.
- **Step 6:** Apply non-maximum suppression on the final edges using Canny() function to thin out the edges.
- **Step 7:** Display the original image and the final edge-detected image using imshow() function.
- **Step 8:** Save the final edge-detected image using imwrite() function.

```
import cv2
# read input image
img = cv2.imread('input.jpg')
# convert image to grayscale
gray = cv2.cvtColor(img, cv2.COLOR_BGR2GRAY)
# apply Gaussian blur to remove noise
blur = cv2.GaussianBlur(gray, (5,5), 0)
# apply Sobel operator to detect edges in x and y directions
sobelx = cv2.Sobel(blur, cv2.CV_64F, 1, 0, ksize=3)
sobely = cv2.Sobel(blur, cv2.CV 64F, 0, 1, ksize=3)
# combine edges detected in x and y directions
edges = cv2.bitwise_or(sobelx, sobely)
# apply non-maximum suppression to thin out edges
edges = cv2.Canny(edges, 100, 200)
# display original image and edge-detected image
cv2.imshow('Original Image', img)
cv2.imshow('Edge-Detected Image', edges)
# save edge-detected image
```

```
cv2.imwrite('output.jpg', edges)
# wait for user to close the window
cv2.waitKey(0)
# close all windows
cv2.destroyAllWindows()
```

6. Feature Description Using SIFT

Write a program to Match two images based on features extracted by SIFT algorithm

Procedure:

- Step 1: Import the necessary libraries and modules of OpenCV and numpy.
- Step 2: Read two images using imread() function
- Step 3: Convert the image to grayscale using cv2.cvtColor() method
- Step 4: Create SIFT feature extractor object using cv2.xfeatures2d.SIFT create ().
- Step 5: Pass the image to detectandCompute() to detect the keypoints and descriptors.
- Step 6: match the descriptors
- Step 7: sort the matches by distance and draw the first 50 matches
- Step 8: Display the image using imshow()
- Step 9: Wait for user input to close the window using cv2.waitKey() method.
- Step 10: Release the resources using cv2.destroyAllWindows() method.

```
# read the images
img1 = cv2.imread('book.jpg')
img2 = cv2.imread('table.jpg')
# convert images to grayscale
img1 = cv2.cvtColor(img1, cv2.COLOR_BGR2GRAY)
img2 = cv2.cvtColor(img2, cv2.COLOR_BGR2GRAY)
# create SIFT object
sift = cv2.xfeatures2d.SIFT_create()
# detect SIFT features in both images
keypoints_1, descriptors_1 = sift.detectAndCompute(img1,None)
keypoints_2, descriptors_2 = sift.detectAndCompute(img2,None)
# create feature matcher
```

```
bf = cv2.BFMatcher(cv2.NORM_L1, crossCheck=True)
# match descriptors of both images
matches = bf.match(descriptors_1,descriptors_2)

# sort matches by distance
matches = sorted(matches, key = lambda x:x.distance)
# draw first 50 matches
matched_img = cv2.drawMatches(img1, keypoints_1, img2, keypoints_2,
matches[:50], img2, flags=2)

# show the image
cv2.imshow('image', matched_img)
# save the image
cv2.imwrite("matched_images.jpg", matched_img)
cv2.waitKey(0)
cv2.destroyAllWindows()
```

7. Geometric Transformations

Implement the following geometric transformations on the image using OpenCV: a)Rotation b)Scaling c) Translation d)Shear

Procedure:

- **Step 1:** Read the input image using cv2.imread() function.
- **Step 2:** Define the transformation matrix M to perform the desired transformation using cv2.getRotationMatrix2D(), cv2.getAffineTransform(), or cv2.getPerspectiveTransform() functions depending on the type of transformation required.
- **Step 3:** Apply the transformation to the image using cv2.warpAffine() or cv2.warpPerspective() function depending on the type of transformation defined in step 2.
- **Step 4:** Display the transformed image using cv2.imshow() function.
- **Step 5:** Wait for a key event using cv2.waitKey() function.
- **Step 6:** Release the memory and destroy all windows using cv2.destroyAllWindows() function.

```
# program to rotate the image
```

```
import cv2
# Read the input image
img = cv2.imread('input.jpg')
# Define the rotation angle
angle = 45
# Get the image dimensions
h, w = img.shape[:2]
# Calculate the rotation matrix M
M = cv2.getRotationMatrix2D((w/2, h/2), angle, 1)
# Apply the rotation to the image
rotated img = cv2.warpAffine(img, M, (w, h))
# Display the original and rotated images
cv2.imshow('Original Image', img)
cv2.imshow('Rotated Image', rotated_img)
# Wait for a key event
cv2.waitKey(0)
# Release the memory and destroy all windows
```

cv2.destroyAllWindows() #Program to scale an image: import numpy as np import cv2 as cv img = cv.imread('girlImage.jpg', 0) rows, cols = img.shape img_shrinked = cv.resize(img, (250, 200), interpolation=cv.INTER AREA) cv.imshow('img', img_shrinked) img enlarged = cv.resize(img shrinked, None, fx=1.5, fy=1.5, interpolation=cv.INTER_CUBIC) cv.imshow('img', img_enlarged) cv.waitKey(0) cv.destroyAllWindows() #program to translate an image import numpy as np import cv2 as cv img = cv.imread('girlImage.jpg', 0) rows, cols = img.shape M = np.float32([[1, 0, 100], [0, 1, 50]])dst = cv.warpAffine(img, M, (cols, rows)) cv.imshow('img', dst) cv.waitKey(0) cv.destroyAllWindows() #program to shear an image import numpy as np import cv2 as cv img = cv.imread('girlImage.jpg', 0) rows, cols = img.shape M = np.float32([[1, 0.5, 0], [0, 1, 0], [0, 0, 1]])sheared_img = cv.warpPerspective(img, M, (int(cols*1.5), int(rows*1.5))) cv.imshow('img', sheared_img) cv.waitKey(0)

cv.destroyAllWindows()

8. Camera Calibration

Write a program to implement camera calibration using OpenCV

Procedure:

- **Step 1:** Capture several images of a calibration pattern (e.g. a chessboard) from different angles with the camera you want to calibrate.
- **Step 2:** Extract the corners of the calibration pattern in each image using OpenCV's findChessboardCorners() function.
- **Step 3:** Create a list of object points, which are the 3D coordinates of the calibration pattern corners in a coordinate system relative to the camera. For example, you can define the first corner as (0,0,0), and then assume that the other corners are on a regular grid of known size.
- **Step 4:** For each image, use OpenCV's cornerSubPix() function to refine the corner coordinates.
- **Step 5:** Use OpenCV's calibrateCamera() function to obtain the camera matrix, distortion coefficients, and rotation and translation vectors for each image.
- **Step 6:** Compute the reprojection error, which measures the average distance between the projected 3D calibration pattern corners and the corresponding 2D image points.
- **Step 7:** Use the obtained calibration parameters to undistort images captured with the calibrated camera using OpenCV's undistort() function.

```
import numpy as np
import cv2
# Define the size of the calibration pattern
pattern_size = (7, 6) # number of interior corners on each row and column
# Define the coordinates of the calibration pattern corners in the
calibration pattern coordinate system
objp = np.zeros((pattern_size[0]*pattern_size[1], 3), np.float32)
objp[:,:2] = np.mgrid[0:pattern_size[0],0:pattern_size[1]].T.reshape(-1,2)
* 30 # assume square size of 30mm
# Capture several images of the calibration pattern from different angles
images = [] # list of images
while True:
ret, img = cap.read() # capture an image from the camera
```

```
if not ret:
break
gray = cv2.cvtColor(img, cv2.COLOR_BGR2GRAY)
ret, corners = cv2.findChessboardCorners(gray, pattern_size, None)
if ret:
cv2.cornerSubPix(gray, corners, (11, 11), (-1, -1), (cv2.TERM_CRITERIA_EPS
+ cv2.TERM_CRITERIA_MAX_ITER, 30, 0.001))
images.append((img, corners))
# Compute the camera calibration parameters
objpoints = [] # list of object points for each image
imgpoints = [] # list of image points for each image
for img, corners in images:
objpoints.append(objp)
imgpoints.append(corners)
ret, mtx, dist, rvecs, tvecs = cv2.calibrateCamera(objpoints, imgpoints,
gray.shape[::-1], None, None)
# Compute the reprojection error
mean error = 0
for i in range(len(objpoints)):
imgpoints2, _ = cv2.projectPoints(objpoints[i], rvecs[i], mtx,
dist)
error = cv2.norm(imgpoints[i],imgpoints2, cv2.NORM_L2)/len(imgpoints2)
mean_error += error
print("Mean reprojection error: ", mean_error/len(objpoints))
# Use the obtained calibration parameters to undistort an image
img = cv2.imread("test.jpg")
undistorted = cv2.undistort(img, mtx, dist)
cv2.imshow("Undistorted image", undistorted)
cv2.waitKey(0)
```

9. Tracking of Moving Objects

Implement optical flow and track moving objects in a video using OpenCV

Procedure:

- **Step 1:** Load the input video and read the first frame.
- **Step 2:** Convert the first frame to grayscale and use it as the reference image.
- **Step 3:** Loop over the remaining frames in the video:
 - a. Convert the current frame to grayscale.
 - b. Compute the optical flow using a method such as Lucas-Kanade or Farneback.
 - c. Compute the magnitude and direction of the optical flow vectors.
 - d. Threshold the magnitude to remove noise and small motions.
 - e. Compute the contours of the thresholded motion map.
 - f. Filter the contours by area and aspect ratio to remove noise and false detections.
 - g. Draw bounding boxes around the remaining contours and track them using a simple Kalman filter or a more sophisticated tracker such as the SORT algorithm.
 - h. Update the reference image to the current frame.
 - i. Display the output video with the bounding boxes around the moving objects.

```
import cv2
import numpy as np
# Load the input video
cap = cv2.VideoCapture('input_video.mp4')
# Read the first frame and convert it to grayscale
ret, frame = cap.read()
gray_ref = cv2.cvtColor(frame, cv2.COLOR_BGR2GRAY)
# Define the motion threshold and contour area threshold
motion_thresh = 50
min_contour_area = 1000
max_contour_aspect_ratio = 5
# Initialize the tracker
tracker = cv2.MultiTracker_create()
# Loop over the frames in the video
while True:
```

```
# Read the current frame and convert it to grayscale
ret, frame = cap.read()
if not ret:
break
gray = cv2.cvtColor(frame, cv2.COLOR_BGR2GRAY)
# Compute the optical flow using Farneback method
flow = cv2.calcOpticalFlowFarneback(gray_ref, gray, None, 0.5, 3, 15, 3,
5, 1.2, 0)
# Compute the magnitude and direction of the optical flow vectors
mag, ang = cv2.cartToPolar(flow[..., 0], flow[..., 1])
# Threshold the magnitude to remove noise and small motions
motion_mask = (mag > motion_thresh).astype(np.uint8)
# Compute the contours of the thresholded motion map
contours, _ = cv2.findContours(motion_mask, cv2.RETR_EXTERNAL,
cv2.CHAIN APPROX SIMPLE)
# Filter the contours by area and aspect ratio to remove noise and false
detections
detections = []
for contour in contours:
area = cv2.contourArea(contour)
bbox = cv2.boundingRect(contour)
aspect_ratio = bbox[2] / bbox[3] if bbox[3] != 0 else 0
if area > min_contour_area and aspect_ratio < max_contour_aspect_ratio:</pre>
detections.append(bbox)
# Update the tracker with the current detections
tracker.update(frame, detections)
# Display the output video with the bounding boxes around the moving
objects
for i, bbox in enumerate(tracker.getObjects()):
x, y, w, h = [int(v) for v in bbox]
cv2.rectangle(frame, (x, y), (x + w, y + h), (0, 255, 0), 2)
cv2.imshow('Output', frame)
if cv2.waitKey(1) == ord('q'):
break
# Update the reference image to the current frame
```

10. KLT Feature Tracker

Implement the Kanade-Lucas-Tomasi (KLT) feature tracker algorithm

- **Step 1:** Load the input video and read the first frame.
- **Step 2:** Select a set of feature points to track using a feature detector such as Shi-Tomasi or Harris corner detector.
- **Step 3:** Compute the optical flow for each feature point using the Lucas-Kanade algorithm.
- **Step 4:** Update the feature points based on the computed optical flow vectors.
- **Step 5:** Loop over the remaining frames in the video:
 - a. Track the feature points using the computed optical flow vectors.
 - b. Compute the optical flow for each feature point using the Lucas-Kanade algorithm.
 - c. Update the feature points based on the computed optical flow vectors.
 - d. Draw the tracked feature points on the output video.

```
import cv2
import numpy as np
# Kanade-Lucas-Tomasi (KLT) Feature Tracker
cap = cv2.VideoCapture('input video.mp4')
# Parameters for Shi-Tomasi corner detection
feature_params = dict(maxCorners=100, qualityLevel=0.3, minDistance=7,
blockSize=7)
# Parameters for Lucas-Kanade optical flow
lk_params = dict(winSize=(15, 15), maxLevel=2,
criteria=(cv2.TERM_CRITERIA_EPS | cv2.TERM_CRITERIA_COUNT, 10, 0.03))
# Take the first frame and detect corners in it
ret, old_frame = cap.read()
old_gray = cv2.cvtColor(old_frame, cv2.COLOR_BGR2GRAY)
p0 = cv2.goodFeaturesToTrack(old gray, mask=None, **feature params)
# Create a mask image for drawing purposes
mask = np.zeros_like(old_frame)
while True:
ret, frame = cap.read()
if not ret:
```

```
break
frame gray = cv2.cvtColor(frame, cv2.COLOR BGR2GRAY)
# Calculate optical flow using Lucas-Kanade algorithm
p1, st, err = cv2.calcOpticalFlowPyrLK(old_gray, frame_gray, p0, None,
**lk_params)
# Select good points
good_new = p1[st == 1]
good_old = p0[st == 1]
# Draw the tracks
for i, (new, old) in enumerate(zip(good_new, good_old)):
a, b = new.ravel()
c, d = old.ravel()
mask = cv2.line(mask, (a, b), (c, d), (0, 255, 0), 2)
frame = cv2.circle(frame, (a, b), 5, (0, 255, 0), -1)
img = cv2.add(frame, mask)
cv2.imshow('frame', img)
if cv2.waitKey(1) == ord('q'):
break
# Update previous frame and points
old_gray = frame_gray.copy()
p0 = good_new.reshape(-1, 1, 2)
cv2.destroyAllWindows()
cap.release()
```

11. Face Detection in Image

Write a program to detect face of a person in a Image

Procedure:

- **Step 1:** Load the pre-trained face detection model using cv2.CascadeClassifier()
- Step 2: Read the input image or stream from a camera
- **Step 3:** Convert the input image to grayscale
- **Step 4:** Detect the faces in the image using cv2.CascadeClassifier.detectMultiScale()
- **Step 5:** Draw a rectangle around each detected face
- **Step 6:** Display the output image with detected faces
- Step 7: Wait for user input to exit or continue processing

```
import cv2
# Load the pre-trained face detection model
face_cascade = v2.CascadeClassifier('haarcascade_frontalface_default.xml')
# Read the input image or stream from a camera
cap = cv2.VideoCapture(0) # Use default camera
while True:
      ret, frame = cap.read()
      if not ret:
           break
      # Convert the input image to grayscale
      gray = cv2.cvtColor(frame, cv2.COLOR BGR2GRAY)
      # Detect the faces in the image
      faces = face_cascade.detectMultiScale(gray, scaleFactor=1.1,
      minNeighbors=5)
      # Draw a rectangle around each detected face
      for (x, y, w, h) in faces:
            cv2.rectangle(frame, (x, y), (x+w, y+h), (0, 255, 0), 2)
      # Display the output image with detected faces
      cv2.imshow('Face Detection', frame)
      # Wait for user input to exit or continue processing
      if cv2.waitKey(1) == ord('q'):
            break
# Release the resources and close the windows
cap.release()
cv2.destroyAllWindows()
```

12. Car Detection in a Video

Write a program to detect a car in the given video using OpenCV

Procedure:

```
Step1: Import required libraries
Step2: Read frames from input video
Step3: Convert frames to grayscale
Step4: Detect cars of different sizes in the input
Step5: Draw rectangle around detected car
Step6: Display video frames in the window
Step7: Loop through all frames for detection
Step8: Destroy all windows
```

```
# import libraries of python OpenCV
import cv2
haar_cascade = 'cars.xml'
video = 'video.avi'
cap = cv2.VideoCapture(video)
car_cascade = cv2.CascadeClassifier(haar_cascade)
# reads frames from a video
ret, frames = cap.read()
# convert frames to gray scale
gray = cv2.cvtColor(frames, cv2.COLOR_BGR2GRAY)
# Detects cars of different sizes in the input image
cars = car_cascade.detectMultiScale(gray, 1.1, 1)
# To draw a rectangle in each cars
for (x,y,w,h) in cars:
cv2.rectangle(frames,(x,y),(x+w,y+h),(0,0,255),2)
# Display frames in a window
cv2.imshow('video', frames)
```

```
# loop runs if capturing has been initialized.
while True:
      # reads frames from a video
      ret, frames = cap.read()
      # convert to gray scale of each frames
      gray = cv2.cvtColor(frames, cv2.COLOR_BGR2GRAY)
      # Detects cars of different sizes in the input image
      cars = car_cascade.detectMultiScale(gray, 1.1, 1)
      # To draw a rectangle in each cars
      for (x,y,w,h) in cars:
            cv2.rectangle(frames,(x,y),(x+w,y+h),(0,0,255),2)
      # Display frames in a window
      cv2.imshow('video', frames)
      # Wait for Esc key to stop
      if cv2.waitKey(33) == 27:
            break
# De-allocate any associated memory usage
cv2.destroyAllWindows()
```